

10-1740 5-ball rack

Attach hanger for Multi-Axial Positioning Board to Ball Rack using the provided screws, nuts, and washers.

Secure wall mount bracket to wall using mounting hardware. Hang 5-ball rack on wall mount bracket.

Remove 5-ball rack from wall mount bracket before inserting or removing instability balls from rack.

10-1744 10-ball rack

Secure 10-ball rack to wall using mounting hardware (not included). Rack should be secured through the 4 wall mount holes.

10-ball rack remains permanently mounted to wall. Insert and remove instability balls directly from wall mounted rack.

instability balls

Instability balls, MVP[®] balance boards, and Multi-Axial Positioning Systems are sold separately.

Please contact your local supplier for more information.





Fabrication Enterprises Inc PO Box 1500 White Plains, NY 10602 (USA) tel: +1-914-345-9300 • 800-431-2830 fax: +1-914-345-9800 • 800-634-5370 FabEnt.com



Authorized CE representative:

Nailsea, Somerset BS48 4NU (UK)

RMS UK Ltd.

28 Trinity Road



related items

instability balls

10-1760 yellow level 1 10-1761 red level 2 10-1762 green level 3 10-1763 blue level 4 10-1764 black level 5

platforms

 10-1776
 16" / 41 cm diameter

 10-1786
 20" / 51 cm diameter

 10-1796
 30" / 76 cm diameter

 10-1756
 15x18" / 38x46 cm

Multi-Axial Platform System 10-1732 board only