



BLUETOOTH 4.0 FTMS
Connects to 3rd Party Apps



OPTIONAL EQUIPMENT

Extended Handrails
TV Bracket (TV not included)

Designed to withstand the rigors of a commercial fitness environment, the CT850 Treadmill combines convenient features with durable construction to provide an exceptional workout experience. The cool running, brushless 4.0 horsepower AC drive motor with a startup speed of only 0.3 mph adds to the reliability while providing the torque and smooth continuous power required for all types of users. The top control panel boasts a simple and intuitive design with direct speed and incline buttons, multiple storage options for water bottles, phones, and other accessories, as well as a built-in fan that helps keep users cool. The ergonomically positioned hand pulse sensors let users easily monitor vital stats, while a variety of built-in programs allow nearly endless workout customization to suit a wide range of fitness levels.

CT850 TREADMILL

- 4.0 horsepower AC drive motor provides superior torque and reliability
- Bright white multi-window LED console is easy to read and simple to use
- Direct speed and incline buttons make workouts more efficient
- Contact and wireless heart rate options to help keep clients in their safe and effective training zone
- Dual-drive motor cooling fans to protect and extend the life of the motor and control board
- Maintenance-free deck system provides hassle-free use for thousands of miles
- Spacious 22" x 60" running deck to accommodate users of all sizes

CT850 TREADMILL



CT850 CONSOLE FEATURES

The electronics in the CT850 are designed to provide simple and intuitive operation. The console features a large easy-to-read display with a variety of program options for users of all fitness levels, an integrated fan to keep clients cool, and a USB port with multiple storage tray options to help keep their devices charged. The addition of direct speed and incline buttons make all workouts more efficient and interval training workouts a breeze.

EQUIPMENT SPECIFICATIONS

Console	white multi-window LED displays (18-character message center, profile matrix, incline, and speed), direct incline and speed buttons, cooling fan, USB charging port, Bluetooth FTMS (connects to fitness apps), C-safe
Programs	manual, interval, 5k, 10k, HIIT, hill, fat burn, cardio, Gerkin Protocol Fit Test, 6 military readiness tests (Army, Navy, Air Force, Marines, PEB, Coast Guard), 2 HR, custom
Heart Rate	contact and Bluetooth compatible (chest strap sold separately)
Speed/Incline	0.3 – 12 mph / 0 – 15%
Power	120 volts (NEMA 5–20P electrical cord); 20-amp circuit recommended
Drive Motor	4.0 HP AC drive with grade H insulation
Deck	maintenance-free, 1" thick, double-sided
Belt	22" x 60", commercial multi-ply
Rollers	commercial grade 3.0"
Storage	reading rack, cell phone ledge, large water bottle storage, and multiple accessory trays
Frame	heavy-gauge high-strength steel with durable powder-coat paint
Dimensions	84" L x 36" W x 61" H
Product Weight	390 lb
Max User Weight	450 lb
Options	extended handrails, TV bracket

WARRANTY INFORMATION

Commercial Warranty (Non-dues Paying Facilities) – Lifetime frame, 5 years motor, deck and parts, and 2 years labor